

SONY®

DATA PROJECTOR

**VPL-ES5
VPL-EX5
VPL-EX50
VPL-EX5U
VPL-EX100**

REMOTE COMMANDER
RM-PJ4

EL9VERDADERO

SERVICE MANUAL
1st Edition (Revised 1)

⚠️ 警告

このマニュアルは、サービス専用です。
お客様が、このマニュアルに記載された設置や保守、点検、修理などを行うと感電や火災、
人身事故につながることがあります。
危険をさけるため、サービストレーニングを受けた技術者のみご使用ください。

⚠️ WARNING

This manual is intended for qualified service personnel only.
To reduce the risk of electric shock, fire or injury, do not perform any servicing other than that
contained in the operating instructions unless you are qualified to do so. Refer all servicing to
qualified service personnel.

⚠️ WARNUNG

Die Anleitung ist nur für qualifiziertes Fachpersonal bestimmt.
Alle Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal ausgeführt werden. Um die
Gefahr eines elektrischen Schlages, Feuergefahr und Verletzungen zu vermeiden, sind bei
Wartungsarbeiten strikt die Angaben in der Anleitung zu befolgen. Andere als die angegebenen
Wartungsarbeiten dürfen nur von Personen ausgeführt werden, die eine spezielle Befähigung
dazu besitzen.

⚠️ AVERTISSEMENT

Ce manual est destiné uniquement aux personnes compétentes en charge de l'entretien. Afin
de réduire les risques de décharge électrique, d'incendie ou de blessure n'effectuer que les
réparations indiquées dans le mode d'emploi à moins d'être qualifié pour en effectuer d'autres.
Pour toute réparation faire appel à une personne compétente uniquement.

警告

電池は、間違ったタイプと交換した場合、破裂の危険がある。
使用済み電池は、地域のルールに従って処分すること。

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE RULE IN REGION.

Table of Contents

1. Service Overview

1-1. Appearance Figure	1-1
1-2. Board Locations	1-1
1-3. Disassembly	1-2
1-3-1. Upper Case Assembly	1-2
1-3-2. Sub Rear Case Assembly	1-3
1-3-3. Main Board	1-3
1-3-4. Power Board and Thermal Sensor Board	1-4
1-3-5. Front Case Assembly and IR Sensor Board	1-5
1-3-6. Fan (Exhaust) -1	1-5
1-3-7. Fan (Exhaust) -2	1-6
1-3-8. Optical Unit Assembly	1-7
1-3-9. Lamp Power Supply	1-8
1-3-10. Fan	1-9
1-3-11. 3D GAMMA Service tool Application Software	1-10

2. Electrical Adjustments

2-1. Initial Values of Adjustment Items	2-1
2-2. Memory Structure	2-7

3. Troubleshooting

3-1. Electric Troubleshooting	3-1
3-2. Power Board Troubleshooting	3-3
3-2-1. No Power	3-3
3-2-2. Failure of Turn on Lamp	3-4
3-3. Optical Troubleshooting	3-6

4. Spare Parts

4-1. Notes on Repair Parts	4-1
4-2. Exploded Views	4-2
4-3. Electrical Parts List	4-4
4-4. Packing Materials & Supplied Accessories	4-4
4-5. Optional Fixtures	4-4

5. Block Diagrams

Overall (VPL-ES5)	5-1
Overall (VPL-EX50)	5-2
Overall (VPL-EX5)	5-3
Overall (VPL-EX5U)	5-4
Overall (VPL-EW5)	5-5


6. Diagrams

6-1. Frame Schematic Diagrams	6-1
Frame (VPL-ES5)	6-1
Frame (VPL-EX50)	6-2
Frame (VPL-EX5/EX5U)	6-3
Frame (VPL-EW5)	6-4


Section 1

Service Overview

1-1. Appearance Figure








1-2. Board Locations




1-3. Disassembly


1-3-1. Upper Case Assembly




1-3-2. Sub Rear Case Assembly





1-3-3. Main Board




1-3-4. Power Board and Thermal Sensor Board






(Refer to section 1-3-3, steps 2 to 6.)





1-3-5. Front Case Assembly and IR Sensor Board



1-3-6. Fan (Exhaust) -1




1-3-7. Fan (Exhaust) -2




1-3-8. Optical Unit Assembly

① Lamp box assembly



(Refer to section 1-3-6, steps 5 to 10) and
(refer to section 1-3-7, steps 1,2, 4 to 6.)



④ Duct lamp assembly

③ Tapping screw (PAN 3 × 10)

⑦ Three tapping screws (PAN 3 × 7)

⑧ Optical unit assembly

Caution :
When attaching the dust lamp assembly, route that harnesses in between the duct lamp assembly and optical unit assembly.

② Two tapping screws (PAN 3 × 7)

Thermal sensor harness,
Fan harness



⑤ Two tapping screws (PAN 3 × 7)

⑥ Focus/Zoom adjust assembly

Assembling method of optical unit assembly and
Focus/Zoom adjust gears assembly



- ⑩ Attach the Focus/Zoom Adjust assembly into the two dowels of the lower case assembly after rotating the Focus/Zoom Adjust assembly as far as it can be rotated in the direction of clockwise direction.

- ⑨ Lens: Rotate the Focus/Zoom gears in the counter-clockwise direction as far as it can be rotated.



- ⑪ Fix the Focus/Zoom Adjust assembly tentatively with the screw.
- ⑫ Rotate the focus adjust gear in the counter-clockwise direction by one tooth. Then, engage these gears with the corresponding lens gears.



Lower case assembly





⑬ Attach the other screw while fixing the gear position.

⑭ Tighten the screw finally that has been tightened tentatively.



1-3-9. Lamp Power Supply



Caution :
When re-assembling the machine,
route the respective harnesses and
wires at the specified locations as shown.



1-3-10. Fan



1-3-11. 3D GAMMA Service tool Application Software

Feature of 3D Gamma Quick Access :

- It can read 3D gamma data from a set and save it in a file.
- It can write 3D gamma data in a PC into a set.

When the optical unit is replaced, load 3D gamma data recorded on the micro floppy disk, which is supplied together with the optical unit, into a set using the application software.

File configuration :


Executable : Ernie Service tool.exe

Readme File : readme_j.txt (Japanese)
readme_e.txt (English)

Software Acquisition :

Download the application software from the GSP website.

- VPL-ES5 set has not RS-232C terminal, use the PCBA MOTOR TEST BD E08S MI.
- Remove the rubber cap on the upper left of the rear side of the unit.



Section 2

Electrical Adjustments

2-1. Initial Values of Adjustment Items

VPL-ES5/EX5/EX50/EX5U/EW5

		VIDEO			S-VIDEO			INPUT A (Component/Video/GBR)			INPUT A (Computer), INPUT B (Computer)		
		Set	Dynamic	Standard	Game	Living	Cinema	Preset- ation	Standard	Game	Living	Cinema	Preset- ation
								*3					
PICTURE SETTING	Picture Mode												
	Adjust Picture												
	Contrast	90	80	90	90	75	85	90	90	90	75	90	85
	Bright	60	50	60	50	55	60	50	50	55	60	50	50
	Color	50	50	68	60	58	50	50	50	58	60	58	50
	Hue	50	50	50	50	50	50	50	50	50	50	50	50
	Sharpness	60	30	50	50	30	50	60	30	40	40	30	40
	DDE	Film	Film	Film	Film	Film	Film	Film	Film	Film	Film	Film	Film
	Gamma Mode												
Color Temp	30												
Volume													
INPUT SETTING		Adjust Signal	Dot Phase	31									
			H Size										
			Shift										
			Aspect	refer to Aspect Default									
SET SETTING		Smart APA	On										
		Auto Input Search	On										
		Input A Signal Sel.	Off										
		Color System	Auto										
		Power Saving Mode	Auto										
		IR Receiver	Off										
		Panel Key Lock	Front & Rear										
		Lamp Timer Reset	Off										
MENU SETTING		Status	On										
		Language	English										
		Menu Position	Center										
		Start Up Image	On										
INSTALL SETTING		Auto Keystone *1	Auto										
		V Keystone *1	0										
		Image Flip	0										
		Background	Off										
		Lamp Mode *1	Blue										
		High Altitude Mode *1	Standard										
		Security Lock	Off										
		Key	Enter x 4										
		Direct Power On	Off										
INFORMATION		All information is display only											

*1: VPL-EX5/EX50/EX5U/EW5 only

*2: VPL-ES5 only

*3: The "Picture Mode" items in the "PICTURE SETTING" menu have their respective initial values for each input signal (PRESET MEMORY No.).

Note

There are some adjustment items that cannot be adjusted, depending on the input signal.

No.	Preset Signal		SVGA(ES5) / XGA(EX5/EX50/EX5U) / WXGA(EW5)		
			PC	Component	Video GBR
1	VIDEO/60	60Hz	-	4:3 / Normal *1	4:3 / Normal *1
2	VIDEO/50	50Hz	-	4:3 / Normal *1	4:3 / Normal *1
3	480/60i	480/60i	-	4:3 / Normal *1	4:3 / Normal *1
4	575/50i	575/50i	-	4:3 / Normal *1	4:3 / Normal *1
5	480/60p	480/60p (progressive component)	-	4:3 / Normal *1	4:3 / Normal *1
6	575/50p	575/50p (progressive component)	-	4:3 / Normal *1	4:3 / Normal *1
7	1080/60i	1035/60i, 1080/60i	-	16:9 / Full *2	16:9 / Full *2
8	1080/50i	1080/50i	-	16:9 / Full *2	16:9 / Full *2
10	720/60p	720/60p	Full1	16:9 / Full *2	16:9 / Full *2
11	720/50p	720/50p	-	16:9 / Full *2	16:9 / Full *2
21 *	640x350	VGA mode1	Full1	-	-
22 *		VGA VESA 85Hz			
23 *	640x400	NEC PC98	Full1	-	-
24 *		VGA mode 2			
25 *		VGA VESA 85Hz			
26 *	640x480	VGA mode 3	Full1	4:3 / Normal *1	4:3 / Normal *1
27 *		Macintosh 13"			
28 *		VGA VESA 72Hz			
29 *		VGA VESA 75Hz (IBM M3)			
30 *		VGA VESA 85Hz			
31 *	800x600	SVGA VESA 56Hz	Full1	-	-
32 *		SVGA VESA 60Hz			
33 *		SVGA VESA 72Hz			
34 *		SVGA VESA 75Hz			
35 *		SVGA VESA 85Hz			
36 *	832x624	Macintosh 16"	Full1	-	-
37 *	1024x768	XGA VESA 60Hz	Full1	-	-
38 *		XGA VESA 70Hz			
39 *		XGA VESA 75Hz			
40 *		XGA VESA 85Hz			
41 *	1152x864	SXGA VESA 70Hz	Full1	-	-
42		SXGA VESA 75Hz			
43		SXGA VESA 85Hz			
44 *	1152x900	SUN LO	Full1	-	-
45 *	1280x960	SXGA VESA 60Hz	Full1	-	-
46		SXGA VESA 75Hz			
47 *	1280x1024	SXGA VESA 60Hz	Full1	-	-
48		SXGA VESA 75Hz			
49 *		SXGA VESA 85Hz			
50	1400x1050	SXGA+ 60Hz	Full1	-	-
55	1280x768	WXGA 60Hz	Full1	-	-
56	1280x720p	WXGA 60Hz	Full1	16:9 / Full *2	16:9 / Full *2
60	1360x768	1360x768/60	Full1	-	-
61	1440x900	1440x900/60	Full1	-	-
63	1280x800	1280x800/60	Full1	-	-

*1: VPL-EW5 : Normal

*2: VPL-EW5 : Full

Page	Item Name	Set			Color		
		ES5	EX5/EX50/EX5U	EW5	R	G	B
P1-1 CXD9809 (ES5) CXD3540 (EX5/EX50/ EX5U/EW5) page1	TGHST Phase Hi	0	—				
	TGHST Phase Lo	109	—				
	SHSH1	38	—				
	TGHST Position	12	—				
	DEHPF On	ON	—				
	DEHPF AAC	ON	—				
	DEHPF TAP	3	—				
	DEUSC On	OFF	—				
	3D GammaSubCont	0	—				
	3D GammaSubBrt	150	—				
	DELUT SW	OFF	ON				
	DEUF SW	ON					
	Full Black/White SW						
P1-2 CXD9809 (ES5) CXD3540 (EX5/EX50/ EX5U/EW5) page2	PC Hi Gain-R	128	512				
	PC Hi Gain-G	128	512				
	PC Hi Gain-B	128	512				
	PC Hi Bias-R	0					
	PC Hi Bias-G	0					
	PC Hi Bias-B	0					
	PC Lo Gain-R	128	512				
	PC Lo Gain-G	70	280				
	PC Lo Gain-B	100	400				
	PC Lo Bias-R	0					
	PC Lo Bias-G	0					
	PC Lo Bias-B	0					
P1-3 CXD9809 (ES5) CXD3540 (EX5/EX50/ EX5U/EW5) page3	Video Hi Gain-R	128	512				
	Video Hi Gain-G	80	320				
	Video Hi Gain-B	120	480				
	PC Mid Bias-R	0					
	Video Hi Bias-G	0					
	Video Hi Bias-B	0					
	Video Lo Gain-R	128	512				
	Video Lo Gain-G	70	280				
	Video Lo Gain-B	100	400				
	Video Lo Bias-R	0					
	Video Lo Bias-G	0					
	Video Lo Bias-B	0					

Page	Item Name	Set			Color		
		ES5	EX5/EX50/EX5U	EW5	R	G	B
P1-4 CXD980 (ES5) CXD3540 (EX5/EX50/ EX5U/EW5) page4	PC Mid Gain-R	128	512				
	PC Mid Gain-G	90	360				
	PC Mid Gain-B	115	460				
	PC Mid Bias-R		0				
	PC Mid Bias-G		0				
	PC Mid Bias-B		0				
	Video Mid Gain-R	128	512				
	Video Mid Gain-G	75	300				
	Video Mid Gain-B	105	420				
	Video Mid Bias-R		0				
	Video Mid Bias-G		0				
	Video Mid Bias-B		0				

P2 Fan Control	Temperature 1	Display only	N/A				
	Temperature 2	Display only					
	Temperature 3	N/A					
	FanSpeed 1	Display only					
	FanSpeed 2	Display only					
	FanSpeed 3	Display only					
	FanSpeed 4	Display only					
	ManualFanSpeed	OFF					
	Burn-In Cycle	0					
	Burn-In Cycle On min.	210					
	Burn-In Cycle Off min.	30					
	Burn-In Hour	50					
	Burn-In active	OFF					


P3-1 CXA7006 (ES5) CXA7009 (EX5/EX50/ EX5U/EW5) page1	Gain-R	154	194	211			
	Gain-G	154	194	211			
	Gain-B	154	194	211			
	SigCen-R	161	47	48			
	SigCen-G	161	47	48			
	SigCen-B	161	47	48			
	SidA-R	22	18				
	SidA-G	22	18				
	SidA-B	22	18				
	SidB-R	85	156	152			
	SidB-G	85	156	152			
	SidB-B	85	156	152			

Page	Item Name	Set			Color		
		ES5	EX5/EX50/EX5U	EW5	R	G	B
P3-2 CXA7006 (ES5) CXA7009 (EX5/EX50/ EX5U/EW5) page2	Bias-R Normal	112	0				
	Bias-G Normal	112	0				
	Bias-B Normal	112	0				
	Bias-R Flip	112	0				
	Bias-G Flip	112	0				
	Bias-B Flip	112	0				
	Vcom-R Normal	88	83	99			
	Vcom-G Normal	88	83	100			
	Vcom-B Normal	88	83	99			
	Vcom-R Flip	88	83	99			
	Vcom-G Flip	88	83	100			
	Vcom-B Flip	88	83	99			
P4 ADC Calibration	RGB Calibrate						
	YUV Calibrate						
	RGB Offset			164	222	164	
	RGB Gain			93	105	93	
	YUV Offset			164	222	164	
	YUV Gain			93	105	93	
	R Offset	164					
	G Offset	222					
	B Offset	164					
	R Gain	93					
	G Gain	105					
	B Gain	93					
P5	Power Saving Time	10					
	System Protect	ON					
	Data Reset						
	Hard Reset *	Not use					
	ROM Version	Display only					
	Lamp Timer	Display only					
	Operation Timer	Display only					
	Prev. Lamp Timer	Display only					
	SOG Threshold	9					
P6 Error Count	All value is display only						

* : Hard reset deletes the adjusted data and restores the default data.

Page	Item Name	Set		
		ES5	EX5/EX50/EX5U	EW5
P7 Keystone Adjustment	average time	—	Display only	—
	Current Y Axis	—	Display only	—
	Current Tout counts	—	Display only	—
	Save T1 data	—	—	—
	T1:	—	1	—
	Axis1:	—	1	—
	Save T2 data	—	—	—
	T2:	—	1	—
	Axis2:	—	1	—
	set manual 'b' left key x	—	1000	—
	a	—	1	—
	b	—	1	—
	Calculate sensitivity	—	—	—
	sensitivity	—	1	—
	current g	—	Display only	—

2-2. Memory Structure



Memory structure of this model consists of the followings.

- 1 Set memory
- 2 Status memory
- 3 Picture memory
- 4 Chroma memory
- 5 W/B memory
- 6 Channel memory

* The gamma memory is realized by giving offset to the Contrast and Brightness output values to the devices in the gamma mode function.

Flow of data is described briefly. When the power plug is connected to the wall outlet for the first time (Standby state), all data that are stored in the internal ROM are written in the NVM (non-volatile memory). When the POWER is turned ON, all the status memory data and other memory data that are required for the present picture are selected from each memory block and expanded in the internal RAM.


When any adjustment is performed at this moment, the adjustment data (user mode items) are written in the NVM (Service/Special Service) automatically triggered by the memory operation.


The adjustment items (W/B, Device Adjust) that can be adjusted in the Service Mode or in the Special Service Mode, are memorized in the NVM at the time when the user performs adjustment and performs the memory operation. Note that the factory adjustment data will be lost at this moment.

Section 3

Troubleshooting


3-1. Electric Troubleshooting







3-2. Power Board Troubleshooting

3-2-1. No Power




3-2-2. Failure of Turn on Lamp





3-3. Optical Troubleshooting



Section 4

Spare Parts

4-1. Notes on Repair Parts

1. Safety Related Components Warning

WARNING

Components marked Δ are critical to safe operation.

Therefore, specified parts should be used in the case of replacement.

WARNHINWEIS

Les composants identifiés par la marque Δ sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

2. Standardization of Parts

Some repair parts supplied by Sony differ from those used for the unit. These are because of parts commonality and improvement.

Parts List has the present standardized repair parts.

3. Stock of Parts

Parts marked with "o" at SP (Supply Code) column of the Spare Parts list may not be stocked. Therefore, the delivery date will be delayed.

Items with no part number and no description are not stocked because they are seldom required for routine service.

4. Units for Capacitors, Inductors and Resistors

The following units are assumed in Schematic Diagrams, Electrical Parts List and Exploded Views unless otherwise specified.

Capacitors : μF

Inductors : μH

Resistors : Ω


5. Note for Electrical key

The components identified by mark \ominus contain confidential information.

Strictly follow the instructions whenever the components are repaired and/or replaced.

Overall

4-2. Exploded Views



No.	Part No.	SP Description
1	△ 1-576-233-51	s FUSE (H.B.C.) (F601)
2	△ 1-576-973-11	s MINIATURE FUSE-LINKS (F602)
3	2-681-550-01	s SCREW, TAP PAN M3*7L
11	9-885-118-05	s WIRE 2P_CON+THERMAL 145MM E08X
12	△ 9-885-118-06	s FAN*2 80*25 170MM AD0812UB/HB
13	△ 9-885-118-07	s FAN 75*75*30 145MM AB7512UB
14	△ 9-885-118-08	s FAN 70*70*25 240MM AB7012UB
15	△ 9-885-118-09	s FAN 60*60*25 183MM AB0612MB
16	9-885-118-10	s PCBA MAIN BD 6L E08X MI (VPL-EX50)
16	9-885-118-11	s PCBA MAIN BD 6L E08XJR MI (VPL-EX5)
16	9-885-118-12	s PCBA MAIN BD 6L E08S MI (VPL-ES5)
16	□ 9-885-118-13	s PCBA MAIN BD 6L E08W MI (VPL-EW5)
16	9-885-122-39	s PCBA MAIN BD 6L E08XU MI (VPL-EX5U)
17	9-885-118-14	s PCBA IR BD E08X MI
18	1-789-544-11	s PCBA THERMAL SENSOR BD MI
19	9-885-118-16	s PCBA POWER BD 2L E08W MI
20	9-885-118-17	s PCBA SWITCH BD E08X MI
21	9-885-118-18	s SPK 2W8OHM 130MM W4028CP-130
22	3-094-309-01	s MYLAR BRIGHTERA E08 (EXCEPT VPL-ES5)
23	9-885-118-22	s DOOR FILTER PC E08X
24	9-885-118-23	s MESH FILTER E08X
25	9-885-118-24	s ASSY ADJ FOOT E08X
26	9-885-118-26	s RUBBER FRONT FOOT E08X
27	9-885-118-27	s NUT HEX+WASHER M3*2.3H NI
28	△ 9-885-118-28	s MYLAR BALLAST PC E08X
29	9-885-118-29	s CAP LENS PC E08X
31	9-885-118-31	s ASSY, UPPER CASE E08X (EXCEPT VPL-EX5U)
31	9-885-121-00	s ASSY UPPER CASE E08XU (VPL-EX5U)
32	9-885-118-32	s ASSY, LAMP DOOR E08X
33	9-885-118-33	s ASSY LAMP BOX E08X
34	9-885-118-34	s ASSY LOWER CASE E08X
35	9-885-118-35	s ASSY REAR CASE E08X (VPL-EX50)
35	9-885-118-36	s ASSY REAR CASE E08XJR (VPL-EX5, VPL-EX5U)
35	9-885-118-37	s ASSY REAR CASE E08S (VPL-ES5)
35	9-885-118-38	s ASSY REAR CASE E08W (VPL-EW5)
36	9-885-118-39	s ASSY FRONT CASE E08X
37	9-885-118-40	s ASSY LAMP NOZZLE E08X
38	9-885-118-41	s ASSY ADJUST GEAR E08 E08X
39	9-885-118-42	s SCREW TAP W/FLA M3x10L PT ZN
40	9-885-118-43	s SCREW TAP W/FLA M3x35 NI D-PT
41	9-885-118-44	s LOGO XGA PC E08X SONY (VPL-EX50)
41	9-885-118-45	s LOGO JR PC E08XJR SONY (VPL-EX5)
41	9-885-118-46	s LOGO SVGA PC E08S SONY (VPL-ES5)
41	9-885-118-47	s LOGO WXGA PC E08W SONY (VPL-EW5)
41	9-885-120-99	s LOGO PC E08XU SONY (VPL-EX5U)
42	2-681-552-02	s SCRW MACH HEX #4-40*4
43	7-682-250-09	s SCRW +K 3X12
44	2-580-599-01	s SCRW +PSW M4X6
45	3-918-696-11	s SCRW (M3X6 LOCK ACE)
46	7-682-903-11	s SCRW +PWH 3X6
47	7-682-954-01	s SCRW +PSW M3X25
51	This part is not supplied as the repair part. If this part is broken or lost, the part reference No. 39 can be used.	
52	This part is not supplied as the repair part. If this part is broken or lost, the part reference No. 46 can be used.	
53	4-654-811-21 s SCRW +F M3X8 EG (VPL-EW5)	

4-3. Electrical Parts List

Ref. No.
or Q'ty Part No. SP Description

1pc ▲ 1-576-233-51 s FUSE (H.B.C) (F601)
1pc ▲ 1-576-973-11 s MINITURE FUSE-LINKS (F602)

4-4. Packing Materials & Supplied Accessories

SUPPLIED ACCESSORIES

Ref. No.
or Q'ty Part No. SP Description

1pc 1-479-775-12 s CARD COMMANDER
1pc 1-832-428-11 s CABLE SINGAL VGA
1pc 9-885-118-30 s BAG CARRY E08X SONY
1pc 3-293-835-03 s CD MANUAL WW E08 E08XJR
(EXCEPT CH/VPL-EX5U)
1pc 3-293-836-02 s MANUAL QUICK REF WW E08 E08XJR
(EXCEPT CH/VPL-EX5U)
(JAPANESE, ENGLISH, FRENCH,
SPANISH, GERMAN, ITALIAN,
SIMPLIFIED CHINESE)

1pc 3-293-838-71 s MANUAL INSTRUCTIONS (CH)
1pc 3-870-419-01 s MANUAL INSTRUCTIONS (E08XU)
(VPL-EX5U)
1pc 3-877-599-11 s MANUAL QUICK REF (E08XU) (VPL-EX5U)
1pc ▲ 1-783-795-64 s CORD SET, POWER (J)
1pc ▲ 1-833-570-11 s POWER-SUPPLY CORD (CH)

4-5. Optional Fixtures


Ref. No.
or Q'ty Part No. SP Description


1pc 9-885-122-51 s PCBA MOTOR TEST BD E08S MI


Section 5

Block Diagrams


VPL-ES5








Overall (VPL-EX5U) Overall (VPL-EX5U)




VPL-EW5

Section 6

Diagrams

6-1. Frame Schematic Diagrams


VPL-ES5



Frame (VPL-EX50)**Frame (VPL-EX50)**

VPL-EX50

1



2

3

4

5


A**B****C****D****E****F****G****H**

Frame (VPL-EX5/EX5U)

Frame (VPL-EX5/EX5U)

VPL-EX5/EX5U


1



Frame (VPL-EW5)**Frame (VPL-EW5)**

VPL-EW5

1

**A****B****C****D****E****F****G****H**

VPL-ES5 (SY)
VPL-ES5 (CH)
VPL-EX5 (SY)
VPL-EX5 (CH)
VPL-EX50 (SY)
VPL-EX50 (CH)
VPL-EX5U (SYY)
VPL-EW5 (SY)
VPL-EW5 (CH) E
9-883-651-02

Sony EMCS Corporation
Ichinomiya Tec

English
2008DR16-1
©2008